

## JTDX/WSJTJX SETTING

The screenshot shows the 'Settings' window with the 'Radio' tab selected. The 'Rig' is set to 'Icom IC-705'. The 'Poll Interval' is '1 s'. The 'CAT Control' section includes 'Serial Port' (COM11), 'Baud Rate' (19200), 'Data Bits' (Default), 'Stop Bits' (Default), 'Handshake' (Default), and 'Force Control Lines' (DTR: Low, RTS: Low). The 'PTT Method' section shows 'CAT' selected. The 'Transmit Audio Source' is 'Front/Mic'. The 'Mode' is 'Data/Pkt'. The 'Split Operation' is 'Fake It'. There are 'Test CAT' and 'Test PTT' buttons, and a 'Tx delay' of '0.1 s'. The window has 'OK' and 'Cancel' buttons at the bottom right.

1. Rig: Icom IC-705
2. Port: Depending on your computer
3. Baud Rate: 19200
4. Data Bits: Default
5. Stop Bits: Default
6. Handshake: Default
7. DTR/RTS: Low
8. PTT Method: CAT
9. Mode: Data/Pkt
10. Split Operation: Fake It

Note:

G90/G90S Fw version  $\geq 1.8$

G106/G106C Fw version  $\geq 1.3$

- End -