

## WR12 Manual

### 4.2 Receiving sensitivity: (AM/NFM/SSB=10dB S/N)

frequency/MHz	AM	NFM	SSB
54~88	0.45uV	0.4uV	0.15uV
88~108	0.4uV	0.35uV	0.15uV
108~200	0.4uV	0.3uV	0.15uV
200~300	0.8uV	0.7uV	0.3uV
300~500	0.4uV	0.3uV	0.15uV
500~700	0.5uV	0.4uV	0.2uV
700~1000	0.6uV	0.45uV	0.15uV

### 5.Packing List

Packing item	Quantity
WR12 component	1
Type-c data cable	1
SAM to BNC RF cable	1
Thumb screw	2
Manual	1
Warranty card	1
Certificate of conformity	1 (printed on the label)
Hex wrench	1

WR12 is an extended component of X6200, which is internally equipped with frequency converters with good sensitivity, linearity, and adjacent channel immunity. It can down-convert the wireless signals to low intermediate frequency signals and transmit them to the X6200 host, increasing the receiving bandwidth of the X6200 host.

#### 1.Installation Steps

① Use the matching hex wrench to unscrew the fixing screws of the small cover plate, and then remove it.




Fig.1 Installation step 1

② Insert the protrusion of the WR12 component into the groove on the top of the X6200 host.




Fig.2 Installation step 2

- ③ After being inserted into the groove, use the matching thumb screw to fix it.




Fig.3 Installation step 3

## 2.Connections for WR12 Component and the X6200 Host

- ① Connect the RIG port of the ANT port of X6200(SAM to BNC RF cable).
- ② Connect the USB port of the WR12 to the host port of X6200(using the type-c data cable).
- ③ Connect the ANT port of the WR12 to the antenna.




Fig.4 Diagram of WR12 and X6200 connection

## 3.Instructions

3.1 After the WR12 component is correctly connected to the X6200 host according to the connection method mentioned above, a blue WR12 logo will appear in the upper right corner of the X6200 main interface, as shown in Fig.5.




Fig.5

### 3.2 The ways of selecting frequency:

Use the X6200 handheld microphone or rotate the large knob of the X6200 host

### 3.3 Working states:

- ① When the frequency is below 54MHz(inclusive), the WR12 component is in a shoot- through state.
- ② When the frequency is higher than 54MHz, select the WR12 component function and the host is in a prohibited transmission state.

## 4. Parameters Design

### 4.1 Working frequency: 54MHz~1000MHz