



## Radioddity X6100-H1 Protection Bracket Installation Guide

### Preparation

Please note you need to prepare a cross screwdriver.



### Installation Steps

(1) **Unscrewing the Side Panel:** Using a Phillips head screwdriver, carefully remove the four screws that are securing the side panel. You can refer to the provided figure for visual guidance.

**Note:** Be sure to store the screws in a safe place for future use.



(2) **Positioning the Gasket:** Next, take the gasket and align it with the four screw holes from which you just removed the screws. The provided figure can help you ensure correct placement.



(3) **Installing the Protective Handle:** Now, gently place the protective handle that you prepared earlier onto the side panel. Make sure to align the handle with the screw holes. Once aligned, proceed to tighten the screws with the equipped hex wrench. Please pay attention to the direction of the protective handle.



(4) **Repeating on the Other Side:** Repeat the same process on the other side of the panel.





(5) **Installing the Antenna Interface Waterproof Cap:** Install the antenna interface waterproof cap. This can be done by hand, similar to tightening a screw. Ensure it's securely fastened.



Note that it's important to handle all components with care to avoid any damage.  
Happy assembling! 😊

## Handle Braiding Guide

For a detailed guide, please refer to the video  
<https://youtu.be/fUJndpD9wxM>





## X6100 Tempered Glass Screen Protector Installation Guide

### Preparation

Clean Your X6100 screen: Work in a clean and well-lit area. Clean your hands thoroughly with warm water and hand soap to remove dirt and grime from your hands. Dry them on a clean towel before you start installing the tempered glass. Clean your X6100 screen before application.

(1) **Remove the Protective Layer:** Peel off the protective layer (named Back ①) from the adhesive side of the glass. Be sure not to touch the adhesive side you just exposed.



(2) **Align the Tempered Glass:** Align the tempered glass with your X6100 screen. Keep it face down as to not attract any dust, and line it up over your X6100.



(3) **Place the Glass on the Screen:** Place the glass on the screen when it is lined up and press lightly in the middle. Then just put pressure in the middle and watch the screen adhere itself.

Happy installing! 😊